

# RESPONSE



## High Powered Led Vehicle Warning Light 80 LED Multi-Pattern User Manual

ST-3278

# High Powered LED Vehicle Warning Light User Manual

ST-3278

Keeping safe on a worksite, or attracting attention to your vehicle at an event. Whatever your purpose, this multi-pattern strobe is versatile and couldn't be easier to install.

Two strong magnets hold it firmly in place on your roof and a curly-cable to cigarette lighter plug means you can power it without any special wiring. Inside the protective plastic case are 80 high power amber LEDs - 10 banks of 8 LEDs each to be precise. There are 10 different display patterns, so you can select the most attention-grabbing one for your situation. Modes include clockwise / anticlockwise rotation, side to side, fade in/out, and more. Two rubber feet on the bottom of the unit cover powerful magnets and protect your paintwork. If you prefer to mount it permanently however, they unscrew for a clean, flush mount. The cigarette lighter plug incorporates an on/off switch with LED power indicator, as well as a switch for selecting the display mode. Of course, please make yourself aware of any local laws for using external lighting on vehicles, on and off public roads.

## FEATURES

- High Power Amber LEDs
- 10 Selectable Flash Modes
- 12 or 24VDC Powered
- Suitable for trucks too

## INSTALLATION

Either use the magnetic mounting feet for temporary installation, or the permanent mounting bolt (drilling of the mounting point may be required for permanent mounting).

### Magnetic Mount Ready



### Bolt-On/Permanent Mount Ready



## TO MOUNT PERMANENTLY

1. Remove rubber surround from magnetic discs.
2. Remove screw from centre of magnetic disc.
3. Remove (4) screws from the centre mounting plate. The plate can now be removed.
4. Insert 10mm bolt, head first, into the bottom of the lightbar.
5. Re-attach centre mounting plate and screws.
6. The lightbar is now ready to be permanently mounted.
7. Place neoprene gasket between the lightbar and the mounting surface.
8. Use the included washer, split washer and nut to finish attaching the lightbar to the mounting surface.

## FLASH PATTERNS

There are 10 available flash patterns.

Flash Pattern	Description
1	Rotating
2	Burst, Fade In-Out/Solid, Fade In-Out
3	Random
4	Burst, Alternating (Side to Side)
5	Burst, Alternating, Diagonal (Front to Back)
6	Burst, Dual Rotating
7	Burst Hold / Burst Side to Side
8	Burst Hold / Single Hold
9	Burst, Single Rotating
10	Burst, Single Rotating

Note: Press pattern button 0.5 seconds for next pattern.

## SPECIFICATIONS

LED: 80 High Power LEDs

Light Colour: Amber

Power: 12/24VDC

Cable: 1m curly cable with cigarette lighter plug

Mounting: Magnetic feet, or permanent screw mount

Dimensions: 280(W) x 165(D) x 62(H)mm (including mounting feet)

## BOX CONTENTS

1 x Magnetic Strobe with Power Cable

2 x Magnetic Feet (Temporary Installation)

1 x Bolt / Nut, washer, split washer & Neoprene Gasket (Permanent Installation)

Distributed by:  
TechBrands by Electus Distribution Pty. Ltd.  
320 Victoria Rd, Rydalmere  
NSW 2116 Australia

Ph: 1300 738 555  
Int'l: +61 2 8832 3200  
Fax: 1300 738 500

[www.techbrands.com](http://www.techbrands.com)