



100W Hot Glue Gun TH1999 User Manual

Technical data:

Voltage input: 240VAC/17W

Power frequency: 50HZ

Power: 100W

Insulation Rate: II

Operation procedure:

1. Insert a 12mm glue stick into the rear entry glue stick holder. Press the trigger gently to make sure the glue stick is positioned well.
2. Connect the unit to a mains outlet.
3. Then Pre-Heat for 4 to 8 minutes. Press the trigger gently and the glue will flow out from Glue Gun.

Cautions:

1. Before using, clear the rear entry glue stick holder very well, inspect the heating to be free of slack or any remains. Also check the power lead to be free of any damaged before use.
2. Do not use near flammable gas or liquid.
3. Do not shake or drop the Glue Gun.
4. Do not leave the Glue Gun unattended when unit is powered.
5. Ensure the Glue Gun has been left unplugged and had time to cool down before storage.

Distributed by:

TechBrands by Electus Distribution Pty. Ltd.

320 Victoria Rd, Rydalmere

NSW 2116 Australia

Ph: 1300 738 555

Int'l: +61 2 8832 3200

Fax: 1300 738 500

www.techbrands.com

Made in China