

V1.10

DRF4432S 20dBm ISM RF Sensor Receiver Module

Features

- GFSK receiver module
- ISM frequency band
- 81K bps data rate
- Multiple channels
- -120dBm sensitivity
- Baud rate configurable
- 256 bytes data buffer
- Standby current < 3uA
- Supply voltage 3.4~5.5V

Application

- Humidity Measurement
- Wireless data logger
- Wireless sensor network
- Home automation
- Temperature Measurement

DESCRIPTION

DRF4432S is a low-cost sub-1 GHz transceiver module designed for operations in the unlicensed ISM (Industrial Scientific Medical) and LPRD bands. GFSK (Frequency Shift Keying) modulation/demodulation, multi-channel operation, high bandwidth efficiency and anti-blocking performance make DRF4432S modules easy to realize the robust and reliable wireless link.

The receiver module DRF4432S is based on si4432 RFIC from Silicon labs and uses the same hardware platform as data transmission module DRF4432D20. It can only be used as receiver in wireless sensor application so it is incompatible with DRF4432D20. DRF4432S is used together with DRF5150S to build wireless sensor applications. It collects sensor data from sensor transmitter modules DRF5150S and transfers data at fixed format which is determined by the sensor working mode configured through DRF Tool 5150.





PIN FUNCTIONS

PIN	Name	Function	Description
1	GND	Ground	Ground (0V)
2	VCC	Power	Power supply
3	/ EN	Input	Enable pin (≤ 0.5): work mode;
			$(\geq 2.0V)$: sleep mode
4	RXD	Input	UART input, TTL level
5	TXD	Output	UART output, TTL level
6	AUX	Output	Data In/Out indication
7	SET		Testing pin, must be floated

 Table 1: DRF4432S Pin Functions

ELECTRICAL SPECIFICATIONS

Symbol	Parameter (condition)	Min.	Тур.	Max.	Units
VCC	Supply Voltage	3.4		5.5	V
Temp	Operating temperature range	-30	25	85	°C
RH	Operating relative humidity	10		90	%
Freq	Frequency range	425	434	450	MHz
Mod	Modulation type		GFSK		
Idd_r	Current in receive mode @ 433Mhz		20		mA
IDD_S	Current in sleep mode @ 433Mhz.		3		uA
Sen.	Receive sensitivity @ 433Mhz, 3.125K bps		-120		dBm
DRFSK	GFSK data rate	3.125	50	81.25	Kbps
DRIN	Serial data rate	1.2	38.4	115.2	Kbps
TE	Evoking time from Sleep to Normal			20	uS
Zant	Antenna Impedance		50		Ohm

 Table 2: DRF4432S Electrical Specifications

ABSOLUTE MAXIMUM RATINGS

Symbol	Parameter	Min.	Max.	Units
VCC	Supply Voltage	-0.3	5.5	V
VI	Input voltage	-0.3	VCC+0.3	V
VO	Output voltage	-0.3	VCC+0.3	V
TST	Storage temperature	-55	125	°C

Table 3: DRF4432S Maximum Ratings



SETTING PARAMETERS

1. Default Values

Parameter	rameter Option		Unit
Serial data rate	1.2~115.2	38.4	Kbps
Parity Check	No check, Even parity, Odd parity	No check	
Frequency	425 ~ 450MHz	434	MHz
GFSK data rate	3.125~81.25	50	Kbps
Group ID	0 ~ 255	123	

Table 4: DRF4432S Default Settings

2. Parameter Setting

Users can configure the parameters (frequency, data rate, group ID, etc.) of DRF modules with RS232 converter board DAC01 or USB converter board DAC02 by configuration tool DRF TOOL5150. Because DRF4432S shares the same configuration tool with DRF5150S, some parameters such as slave ID, Tx interval, etc are not applicable for receiver module DRF5150S.

Firstly users need to insert module into converter board, connect converter board to PC and then open DORJI RF software. In Windows XP system, the software can be run directly but in Windows Vista/7 system users should run it as administrator. After that the status column of tool should display "Found Device". Users then can read/write the module. For more details, please check the operation manuals of converter boards on accessory page.





Rf from 424	MUS PErson Datasa
In med 404	MH2 AI power [3(MAX)
Rf Rate 50Kbps	▼ Tx Interval 4sec ▼
Series Parameters	
Series Rate 3840	DObps 💌 Series Parity Disable 💌
Sensor	
Group ID 123	Slave Id 123 🔽 Slave ID Inc
Sensor Type DS181	B20 (High Resolution Mode) 🔹
н	figh Resolution Mode
	GND
	+3.0 to 3.6V GND 2 VCC
D\$18820	3 VCC DRE5150
12bit Resoluti	AD1/RXD
VDD 2	5 AD2/TXD
GND 1	6 AUX
Format : TD(2b)	yte)+Data(2byte)+Bat(1byte)+RSSI(1byte)
ronac. inter	\mathbf{T} TRISECE 2 SV 2 TAV \mathbf{r} is shown in 1/4
Conditional better	a second i i i i i i i i i i i i i i i i i i i
Conditions:batter Average current	: Battery life:
Conditions:batter Average current	: Battery life:

Figure 1: DRF TOOL 5150

The sleep mode of DRF4432D20 is realized through software. In sleep mode, the levels of DRF4432S module remain the same status before entering sleep mode so the module can quickly enter receive mode. The switching time from sleep mode to receive is about 20us. Please note that the DRF4432S module only can enter into sleep mode after receive process is finished and the AUX pin is kept in low.



RSSI vs Input Power



Figure 2: RSSI Value vs Input Power



MECHANICAL DATA

Figure 3: Mechanical Dimension



ORDERING INFORMATION

$\underline{\text{DRF}}\,\underline{4432}\,\underline{\text{S}}\,\underline{12}\,\underline{-\,043}\,\underline{\text{A}}$

1 2 34 5 6

Num	Symbol	Meaning
1	RF module	DORJI RF GFSK module
2	ІС Туре	SI4432
3	Module Function	Data transmission
(4)	Sensitivity	-120dBm sensitivity
5	Freq. Band	043: 433MHz 086:869Mhz 091:915Mhz
6	Package	DIP package with SMA connector

 Table 5: Ordering Information

	Dorji Industrial Group Co., Ltd reserves the right to
	make corrections, modifications, improvements and
	other changes to its products and services at any time
Dorji Applied Technologies	and to discontinue any product or service without
A division of Dorji Industrial Group Co., Ltd	notice. Customers are expected to visit websites for
	getting newest product information before placing
Add.: Xinchenhuayuan 2, Dalangnanlu, Longhua,	orders.
Baoan district, Shenzhen, China 518109	
Tel: 0086-755-28156122	These products are not designed for use in life support
Fax.: 0086-755-28156133	appliances, devices or other products where
Email: sales@dorji.com	malfunction of these products might result in personal
Web: http://www.dorji.com	injury. Customers using these products in such
	applications do so at their own risk and agree to fully
	indemnify Dorji Industrial Group for any damages
	resulting from improper use.