

EN | DESK LAMP

TECHNICAL CHARACTERISTICS:

Material: ABS and rubber

Power Input: DC 5V 800mA

Type of lamp: LED

Color temperature of the light: 5500 to 6000 ° K

Maximum luminous intensity: 120 Lm

Lamp power: 2.0W

Battery type: Lithium

Includes:

Touch button to change intensity level

Three levels of intensity

Flexible arm

Includes USB cable for battery charging

METHOD OF USE:

- Before first use the battery must be charged for at least 8 hours; the battery is fully charged after 12 hours.
- When the battery is fully charged, the lamp has autonomy for 12 hours at the minimum illumination level, 8 hours at the intermediate illumination level and 5 hours at the maximum illumination level.
- The tactile button allows you to change the intensity level of the lighting; with one touch the lamp works at the minimum level of intensity, two taps at the intermediate level and 3 taps for maximum illumination.
- When you notice that the lamp is losing intensity, it means the battery is discharged. Turn off the lamp and recharge the battery. In this way, you avoid damaging the performance of the batteries and reducing their life time.
- If the lamp is not used for a long period of time, charge the battery at least twice a month for a minimum of 8 hours. This prolongs the life time of the battery.