

KITRONIK **RESOURCES**



INTRODUCTION

Learn how to make a clock interface to change and set the time with the Halo HD.

If you have not done the 'Basic Clock Tutorial', it is recommended that you complete it first.



SETTING UP

EQUIPMENT REQUIRED:

- 1 x BBC micro:bit (www.kitronik.co.uk/5613),
- 1 x Halo HD Alarm Clock Kit (<u>www.kitronik.co.uk/5681</u>)

ADDING IN CUSTOM MAKECODE BLOCKS:

We have made custom coding blocks especially for the Halo HD, which helps to make coding super simple within Microsoft MakeCode.

To add these blocks, follow the steps below:

STEP 1: Bring up the MakeCode Block Editor - (makecode.microbit.org).

STEP 2: Click 'New Project'.

STEP 3: In the toolbox towards the left of the screen, select the **'Advanced'** section. Additional block categories will appear below.

STEP 4: Select 'Extensions'.

STEP 5: In the pop up's search bar type 'Kitronik'.STEP 6: Locate & select the 'kitronik-halohd' box.

🗧 Go back Extensions kitronik Q kitronik-servo-lite kitronik-motor-driver kitronik-I2C-16-servo kitronik-halohd Custom Blocks for driving the Kitronik Halo HD for the BBC Blocks for driving the Kitronik I2C 16 servo expansion board Blocks for driving Kitronik micro:bit Blocks for driving the Kitronik micro:bit motor driver board boards Learn mor Learn more Learn mo







THE TUTORIAL

RECREATE BASIC CLOCK CODE

STEP 1: From the first tutorial, we had the code for displaying the time. Start by recreating that program, but remove the 'set time' block from the 'on button pressed' block.





CHANGING MINUTES

STEP 1: Next, two variables are required for the interface for setting the time. Create one variable called 'setTimeMode' and another called 'enterNewTime'. Add them to the 'on start' block and set them to 'false' using the block in the 'logic' section.



STEP 2: The code needs to be told that we are in "setTime" mode.

To do this, place an 'if else' statement in the 'on button A+B pressed' to check if the variable 'setTimeMode' equals 'true'.





STEP 3: Each section of the 'if else' statement needs to set one of our new variables to be 'true'. The code needs to be:

if 'setTimeMode' is 'true', set 'enterNewTime' to 'true', else 'setTimeMode' to 'true'. So, if the program is in the "setTime" mode, the 'A+B' button press will confirm and enter the new time settings.



STEP 4: Going back to the 'forever' loop, we need to add an 'if else' statment to check if we are in "setTime" mode. The 'if' statement needs to check whether the 'setTimeMode' variable equals 'true', 'else' run the code for displaying the time.

forever					
if	setTimeMode 🕶	= 🔻 tr	ue 🕶 then		
else			Θ		
	haloDisplay 👻	clear			
	haloDisplay 🗢	set ZIP LED	Read seconds -	for ZIP display	to red 🔻
	haloDisplay 🔻	set ZIP LED	Read minutes -	for ZIP display	to green 🔻
	haloDisplay 🔻	set ZIP LED	Read hours -	for ZIP display	to blue 🔻
	haloDisplay 🔻	show			
•					





STEP 5: Next, we need to create two more variables: 'minutes' and 'hours'. These will be the values for setting the new time.

STEP 6: The new variable 'minutes' needs to be set to the current minute reading on the clock. Inside the Clock section of the Halo HD extension, there is a 'read time as number' block. Set 'minutes' to be equal to this and select 'minutes' from the drop-down.

Place the 'set minutes' block into the first slot of the 'if else' statement in the 'forever' loop.



STEP 7: See if you can create the blocks that read and set the hours...

HINT: It's the same blocks, but with different selections on the drop-downs.

STEP 8: As the RTC is setup in 24 hour mode, we also need to add in a quick check at this point to make sure we don't try and display 24 hour time on a 12 hour clock! Use an 'if' statement to check whether the read hours is greater than or equal to 12, and if it is, take 12 from it's value.





STEP 9: Now that we have the current minutes and hours stored as variables, we can change their values and use them to set a new time.

Whilst we are setting a new time, the Halo HD needs to display the values we are changing, until we confirm the new settings. To do this, add a 'while' loop after the 'set hours' block. The loop should continue while the variable 'enterNewTime' is 'false'.



STEP 10: In the loop, we need to display the time values we are changing. The code is very similar to our clock display code. See if you can remember how we did that, and then modify the code to display our variables.







STEP 11: Now there needs to be a way to increment the 'minutes' value. We will do this with the 'on button A pressed' block. Make it change the 'minutes' variable by 1 each time.



STEP 12: Only increasing the 'minutes' by 1 could make setting the time a very long process; it would be nice to have a much quicker way.

Using the 'on button B pressed' block, see if you can make the 'minutes' variable change by 10.

on buttor	n B ▼ pre	essed	
change	minutes 🔻	by	10

STEP 13: To make sure the micro:bit has time to check for the button presses, a short 'pause' of 1ms needs to be added to the end of the 'while' loop.



STEP 14: If you have a micro:bit connected, click 'Download' to transfer your code.

Test the code by pressing 'A+B' to get into time setting mode and using the 'A' and 'B' buttons to change the 'minutes' value.

HINT: Test what happens when the 'minutes' value is increased beyond the next hour.



SETTING THE TIME

STEP 1: Did you set the minutes past the hour? You might have noticed that the LED disappears. This is because the value of 'minutes' becomes greater than the number of LEDs on the Halo HD. To correct this, we can use an 'if' statement to check if 'minutes' is greater than... which number do you think? Place this 'if' statement at the start of the 'while' loop.



STEP 2: Now we have the check in place, the 'minutes' variable needs to be set back to 0 when the condition is met. Add the appropriate block inside the 'if' statement.

while enterNewTime = false
do if minutes ▼ >▼ 59 then
set minutes ▼ to 0
haloDisplay 🔻 clear
haloDisplay ▼ set ZIP LED minutes ▼ to green ▼
haloDisplay ▼ set ZIP LED hours ▼ to blue ▼
haloDisplay - show





STEP 3: Since 'minutes' has gone past the hour and been set back to 0, that means that the hour must have changed as well. Add a block to the 'if' statement to change the 'hours' variable by 1.

while enterNewTime = false
do if minutes ▼ >▼ 59 then
set minutes → to 0
change hours → by 1
haloDisplay - clear
haloDisplay ▼ set ZIP LED minutes ▼ to green ▼
haloDisplay ▼ set ZIP LED hours ▼ to blue ▼
haloDisplay show

STEP 4: If you have a micro:bit connected, click 'Download' to transfer your code. Again, test the code by going into time setting mode and increasing the value of 'minutes'.

HINT: Test what happens now when we increase to the next hour.

STEP 5: At the moment, when we increase the 'minutes' and cause the 'hours' to move forward, the 'hours' only move on by a single ZIP LED. This is not correct, as the hour marks on the Halo HD are actually every 5 ZIP LEDs. This is easy to fix. In the block where we set the ZIP LED for the 'hours', change it so it reads:







STEP 6: Just as the 'minutes' need resetting when they pass the 59th minute, the 'hours' needs resetting when they pass the 11th hour.

See if you can add the code to reset the 'hours' back to 0.



STEP 7: Once we have reached the time we want to set, pressing buttons 'A+B' will exit the 'while' loop. Now we need to save this new time to the Halo HD.

Inside the Clock section of the Halo HD extension, there is a 'set time' block. Add this after the 'while' loop and insert the 'hours' and 'minutes' variables into the appropriate fields. Finally, we just need to set 'enterNewTime' and 'setTimeMode' back to false (this is to make sure the code does not loop back around into "setTime" mode again and displays the new time instead).



STEP 8: CODING COMPLETE! Let's click 'Download' and transfer your code to the Halo HD and enjoy a colourful clock with time setting functionality. (See next page for complete code).









For any further queries or support, please visit the Kitronik website: www.kitronik.co.uk/5672

Or get in touch:

Telephone +44 (0) 115 970 4243 Sales email: sales@kitronik.co.uk Tech Support email: support@kitronik.co.uk Web: www.kitronik.co.uk



kitronik.co.uk/facebook

kitronik.co.uk/youtube

kitronik.co.uk/instagram

Designed & manufactured in the UK by Kutronik

