

ALH-PIR360

Instructions

Thank you for choosing the ALH-PIR360 for your security system. The ALH-PIR360 is a high-performance infrared motion detector designed to provide excellent 360-degree coverage, ideal for use as a ceiling mount detector. Ceiling mount detectors are highly recommended in areas where objects can block the view of regular wall or corner mount detectors (usually the case in office buildings).

The ALH-PIR360 oval detection pattern coverage provides an excellent coverage range up to 6m when installed as low as 2.4m, increasing to up to 10m range at higher mounting positions.

To open the detector: Turn the cover counterclockwise. To replace the lens, gently push the lens and bezel out of the cover. To reinstall the lens, align lens and bezel. Between pin inside cover and make sure that the bezel snaps in the cover.

To close the detector: Align the arrow in the cover with the arrow on the PCB and turn the cover clockwise.

After selecting the detector location, drill screw holes A and B. The PCB should be carefully removed by loosening the PCB screw. Run the wires through entry holes C, D and E and connect them according to the PCB markings.

