



How to assemble the RPi touchscreen display




RaspberryPi


1.



2.




3.



Parts List

1. 7" Touch screen display
2. Display ribbon cable
3. 4 x jumper wires
4. 4 x stand-offs
5. 4 x screws
6. Adapter board

6.




4.



5.



STEP 1



Connect the display ribbon cable to the back of the adapter board (Panel 2)

STEP 2




Lie the adapter board onto the back of the display then connect the touch screen ribbon cable into J4 (Panel 1)




STEP 3



Attach the 4 x Standoffs & screw them through the adapter board into the back of the display




STEP 4



Attach the DSI ribbon cable to the Adapter Board

STEP 5




Use the 4 x screws to secure the Raspberry Pi board to the Standoffs then connect the DSI ribbon cable to the Raspberry Pi




STEP 6

Connect the jumper wires from the Raspberry Pi to the adapter board



Pin#	NAME	NAME	Pin#
01	3.3v DC Power	DC Power 5v	02
03	GPIO02 (SDA1 , I2C)	DC Power 5v	04
05	GPIO03 (SCL1 , I2C)	Ground	06
07	GPIO04 (GPIO_GCLK)	(TXD0) GPIO14	08
09	Ground	(RXD0) GPIO15	10
11	GPIO17 (GPIO_GEN0)	(GPIO_GEN1) GPIO18	12
13	GPIO27 (GPIO_GEN2)	Ground	14
15	GPIO22 (GPIO_GEN3)	(GPIO_GEN4) GPIO23	16
17	3.3v DC Power	(GPIO_GEN5) GPIO24	18
19	GPIO10 (SPI_MOSI)	Ground	20
21	GPIO09 (SPI_MISO)	(GPIO_GEN6) GPIO25	22
23	GPIO11 (SPI_CLK)	(SPI_CE0_N) GPIO28	24
25	Ground	(SPI_CE1_N) GPIO27	26
27	ID_SD (PC ID EEPROM)	(PC ID EEPROM) ID_SC	28
29	GPIO05	Ground	30
31	GPIO06	GPIO12	32
33	GPIO13	Ground	34
35	GPIO19	GPIO16	36
37	GPIO26	GPIO20	38
39	Ground	GPIO21	40

Rev. 1
26/10/14
<http://www.element14.com>



STEP 7

Insert a Micro SD Card into the Raspberry Pi with the Latest version of Raspbian installed then attach a 2Amp Power Supply to the Raspberry Pi Adapter Board to power the display and Raspberry Pi Board.



STEP 8

Operating Software:

Now that you've assembled your Raspberry Pi Touchscreen Display, you will need to download and install the latest version of the Raspbian Operating System - available to download from the Raspberry Pi Foundation at: <https://www.raspberrypi.org/downloads/>

Once installed, type

```
sudo apt-get update
```

and

```
sudo apt-get upgrade
```

(in that order) to install all of the latest drivers and software to support the Touchscreen Display.

