

### 10W Audio Mono Amplifier Module 12VDC ARD2-2175

- Onboard TDA2030A audio power amplifier chip
- Mono 10W @ 4Ω / (5W @ 8Ω) power amplifier circuit design
- Onboard 10 k adjustable resistance, can adjust the volume of the amplification
- Onboard LED power light

#### Description

TDA2030A audio amplifier circuit, using 4-pin single in-line pin (VCC : AUDIO IN : AUDIO GND : POWER GND). The integrated circuit is widely used in car stereo receiver tape recorders, medium-power audio equipment, with small size, large output power, low distortion and other characteristics. It also has an internal protection circuit. Uses 2pin screw terminal for Speaker Audio Output.

#### Specifications

<b>Audio Output</b>	10W @ 4Ω
	5W @ 8 Ω
<b>Working Voltage</b>	12 VDC
<b>Board Dimensions (LxW)</b>	32 x 24 mm
<b>Weight</b>	9.9 g

