



Commercial LED High Bay Lighting

LHB-D Series: Commercial chain mount high bay lighting in 100W, 150W and 200W models

The ENSA™ LHB-D high bay series delivers energy efficient lighting to industrial and commercial environments at an economic price point. They are also weather-resistant, making them ideal for outdoors installations and events.

The LHB-D series delivers ideal lighting conditions in areas with high ceilings up to 12m, such as warehouses, manufacturing facilities and exhibition halls, with a high luminous efficacy for optimal power consumption. Each light has a compact, robust aluminium body and comes in 5700K cool white colour temperature.

- 100W, 150W and 200W industry-ready LED high bay light
- High 130lm/W luminous efficacy for energy efficiency
- Includes G1/2" thread hook for chain mount & safety cable
- 180° U-bracket and G1/2" pole mount (optional)
- Compact and robust: no additional reflector required
- Efficient heatsink cooling technology, IP66 weather rated
- Available in 5700K cool white colour temperature
- Available in 60°, 90° and 120° beam angles

Series Specifications

Model	LHB-D100	LHB-D150	LHB-D200						
Product Image	P P	E	P Common of the						
Series Name	LHB-D Series: Commercial LED High Bay Series								
Optical									
Light Output	13000lm	19500lm	26000lm						
Luminous Efficacy		130lm/W							
Colour Temperature									
Colour Rendering Index		>80							
Beam Angle	90° (standard) / 120°	90° (standard) / 120°	60° / 90° (standard) / 120°						
Rated Lifespan		50,000 hours							
Electrical									
Power Consumption	100W	150W	200W						
Input Voltage		100~277VAC							
Power Factor		> 0.93							
Dimmable	N/A								
General									
Ingress Protection	IP66								
Plug / Socket / Base	3-pin AC plug								
Reflector / Diffuser		Aluminium / Polycarbonate							
Housing Adjustments	G1/2" thread								
Operating Environment	-20 ~ 40°C								
Dimensions	Ø300 x 155mm	Ø330 x 155mm	Ø390 x 155mm						
Photometry									
Illuminance at a Distance	Centre Beam Avg (lx) Beam Diameter (m) 2978 2.05 744 4.11 6m 331 6.16 8m 186 8.22 10m	Centre Beam Avg (lx) 1m 4511 1.98 2m 1128 3.97 3m 501 5.95 4m 282 7.94 5m 180 9.92	Centre Beam Avg (lx) 1m 5923 1.98 2m 1481 3.95 3m 658 5.93 4m 370 7.91 5m 237 9.88						
Luminous Light Distribution	90° 75° 45° 30° 15° 0° 15° 30°	90° 75° 60° 45° 8000 45° 8000 15° 0° 15° 30° 15° 30°	90° 75° 3000 45° 90° 15° 0° 15° 0° 15° 30°						

Ordering Information

Type		Series	Wattage		Colour Temperature	Beam Angle			
LHB	-	D	100 (100W) 150 (150W) 200 (200W)	-	C (Cool white)	90	(60°, 200W only) (90°) (120°)		
LHB-D150-C90: 150W LED High Bay in Cool White (90°)									

Your local ENSA™ lighting solutions professional:

Additional Accessories

The optional **180° U-bracket mount** and **G1/2″ pole mount** open up more installation opportunities for the LHB-D series.

