

Assembly Instructions:

1. Solder the resistors and diode in position, ensuring correct polarity of the diode.
2. Solder the stereo download socket sockets in position. Ensure the stereo socket 'clicks' into position flat on the PCB prior to soldering (it does not matter if solder joins the two 'pairs' of contacts each side).
3. Solder the 8 pin IC socket in position. Note that due to an unavoidable change in brand of the stereo socket, clearance between the IC and stereo socket is now very tight. Ensure all 8 pins of the IC socket can be soldered by pushing the socket in place at a slight angle.
4. Solder the capacitors in position. Ensure correct polarity of the two tantalum capacitors (long leg is +ve).
5. Solder the 4x 3-pin headers (snapped to size from 10 way header) and the 2 way terminal block in position.
6. Insert the PICAXE-08M2 microcontroller supplied into the 8 pin socket, pin1 to the left.

PICAXE-08M2 Input/Output Pin Connections:

Outputs 0, 1, 2 and 4 are connected to the three pin servo headers. The three pins provide 0V, V+ and signal. Although these pins are normally used as outputs, they may also be used as inputs if desired.

Remember that this output 0 is also used as the serial output pin and so will 'pulse' on and off during a new PICAXE program download.


Input 3 is already connected to a 10k pull-down resistor and so a switch may be directly connected between the two pads at the bottom of the board.

Connecting Servos:

Each servo should be connected to the three pin header (output 0, 1, 2 or 4). The black wire of the servo should be connected to the inner pin (yellow/white wire on outside of PCB).

Power Supply:

The servo driver board is designed to operate at 6V (4 x alkaline cells) or 4.8V (4 x rechargeable cell). A diode provides a 0.7V voltage drop before the PICAXE chip, which therefore operates at an acceptable maximum of 5.3V. **Do not** use a 7.2V or 9V battery pack without regulating the PICAXE supply to 5V, as this will damage the PICAXE chip. The board will also operate from a regulated 5V or 6V DC supply.



Electrical Noise:

Servos can produce a large amount of electrical noise whilst operating. If your program behaves erratically, particularly resetting often, this can be a symptom of electrical noise on the power rails. Simply remove the servo and test the program again - if normal operation follows removal of the servo this will isolate the problem to noise from the servo. Use further capacitors to suppress the noise on the power rails.

Sample Program:

This sample program will operate 3 servos on the outputs 1, 2 and 4.

```
**** Program constants
' Delay to slow down servo motion (30ms default)
  symbol servo_delay = 30

**** Initialisation
init:
' set servos to known position
  servo C.1,120
  servo C.2,120
  servo C.4,120
  pause servo_delay

**** Move forward
move_forward:
  for b1 = 120 to 180
    servopos C.1,b1
    pause servo_delay
  next b1

  for b1 = 120 to 180
    servopos C.4,b1
    servopos C.2,b1
    pause servo_delay
  next b1

  for b1 = 180 to 120 step -1
    servopos 1,b1
    pause servo_delay
  next b1

  for b1 = 180 to 120 step -1
    servopos C.4,b1
    servopos C.2,b1
    pause servo_delay
  next b1

  goto move_forward
```