

Complete 360° Al coverage.

Fisheye Al Series: 360° Fisheye IP Camera with Al people counting in 5.0MP

The Fisheye Al Series 360° dome performs the duties of multiple cameras, with the powerful benefit of Al-powered people counting and heat mapping functions. Receive real-time alerts when a certain number of people enter an area with Al people & area counting or set up heat map to observe the amount of time people spend in areas.

- Stream up to 5.0MP (2592 x 1944) at 25fps
- Circular fisheye lens with 360° viewing angle
- Dewarp modes* for ceiling, floor & wall mounting
- Virtual PTZ, panorama, & camera split dewarp modes
- Up to 10m infrared range; true day/night (auto ICR)
- Al-enhanced people counting/tracking for real-time alerts, statistics and business analytics
- Heat map, gueue management & regions of interest
- IVS functionality including tripwire, intrusion & more
- MicroSD card slot for edge recording up to 256GB



Record Beyond Double Full HD



Fisheye Image Dewarp Modes



AI-Enhanced People Counting

Specialist AI Series People Counting Fisheye | Series Specifications

Sp	ecifications		5.0MP 360° Fisheye with AI People Counting
Mo	Product Image		TAVE TO THE PART OF THE PART O
Or	Ordering Information		VSIPFE-5IR-I
lm	Image Sensor		1/2.7" 5.0MP Progressive Scan CMOS
es Eff	Effective Pixels		2592 (H) x 1944 (V)
₹ RA	RAM / ROM		512GB / 128GB
ভ Mi	Min Illumination		0.006 Lux/F2.0
S/	S/N Ratio		>56dB
In	Infrared System		3 x Infrared LED, 10m range
Le	Lens / Iris Field of View		1.4mm F2.0 Fixed Focal Lens with Fixed Iris
돌 Fie			Horizontal: 180°, Vertical: 180°
Fo	Focus		0.2m Min. Focus Distance
DO	OORI		Detect (25px/m): 28m / Observe (63px/m): 11.2m / Recognise (125px/m): 5.6m / Identify (250px/m): 2.8m
Re	Resolution		5.0MP (2592 x 1944) to CIF (352 x 288)
	Frame Rate	Main	5.0MP (1 ~ 25fps)
Fr		Sub	D1 (1 ~ 25fps)
		Third	720p (1 ~ 25fps)
Vi	Video Compression		H.265+, H.265, H.264+, H.264, H.264H, H.264B, MJPEG
Bi	Bit Rate		H264: 3Kbps-8192Kbps; H265: 3Kbps-8192Kbps
ខ្ល Bir	Bit Rate Control		Constant bit rate (CBR) / Variable bit rate (VBR)
ĕ Da	Day/Night		Auto (ICR) / Color / B&W
Lig	Lighting Compensation		BLC / HLC / WDR (120dB)
Sn	Smart Scene Adaptive		Yes
W	White Balance		Auto / Natural / Street Lamp / Outdoor / Manual / Regional Custom
Ga	Gain Control		Auto / Manual
No	Noise Reduction		3D DNR
De	Dewarping Modes		Original (no dewarp) / Panoramic / Double Panoramic / Virtual PTZ / Original + 3 split, + 4 split, + 8 split
In	Intelligent Functions		Check the Supported NVR specification to see if Fisheye Dewarping is supported by that NVR model Intrusion, Tripwire, Motion Detection (4 zones), Region of Interest (4 zones), Privacy Masking (4 zones) Smart Infrared, Heat Map
People Counting			Area People Counting (Number of people, People quantity thresholds, 4 zones), Heat Mapping (Number of people and time spent)
	hernet	9	RJ-45 (10/100Base-T)
₹ —	Protocol		IPv4; IPv6; HTTP; HTTPS; TCP; UDP; ARP; RTP; RTSP; RTCP; RTMP; SMTP; FTP; SFTP; DHCP; DNS; DDNS; QoS; UPnP; NTP; Multicast; ICMP; IGMP; NFS; PPPoE; 802.1x; SNMP
Streaming Method		nod	Unicast / Multicast
Max. User Access			20 Users (Total bandwidth: 64M)
Video Interface			N/A
Audio Interface			1 Channel Input (RCA), 1 Built-in Mic / 1 Channel Output / Audio Compression: PCM, G.711A, G.711Mu, G726, AAC
ğ Al	Alarm Interface		1 Channel Input (5mA 3VDC ~ 5VDC) / 1 Channel Output (300mA 12VDC)
e RS	RS485		N/A
Ed	Edge Storage		MicroSD Card (up to 256GB) / FTP / SFTP / NAS
Int	Interoperability		ONVIF (Profile S / Profile G / Profile T), CGI, Milestone, Genetec, P2P
Po	Power Supply		12VDC / PoE
Po	Power Consumption		<3.6W (12VDC) / <4.4W (PoE) / <8.8W (Max.)
를 이	Operating Conditions		-10°C to +50°C, ≤95% RH
ln	Ingress Protection		N/A
Va	Vandal Resistance		N/A
ξ Hα	Housing		Metal + Plastic
T Pa	Pan/Tilt/Rotation		N/A
Di	Dimensions		Ø126.2mm x 44.6mm
Ne	Net Weight		0.3kg

