



# TDS + EC Water Quality Tester

With Temperature Displayed

- TDS PPM & EC  $\mu\text{S}/\text{cm}$
- Shift between TDS and Conductivity
- Automatic Shutdown
- Monitor Food & Drink
- Monitor Pools & Spas

This 3 in 1 Water Quality Tester has an auto-off function that turns off the meter after 5 minutes of inactivity to save batteries. It also has automatic temperature compensation and can shift between TDS and Conductivity. It can be used in water purifiers and filters, food (vegetable, fruit) & drink quality monitoring, pools, and spas, aquarium, hydroponics.



**ME4329**

## Product Specifications

<b>Conductivity</b>	0 - 9999 $\mu\text{S}/\text{cm}$
<b>TDS</b>	0 - 9999 ppm
<b>Degrees Celsius</b>	0.1 - 80.0 $^{\circ}\text{C}$
<b>Degrees Fahrenheit</b>	32.0 - 1776.0 $^{\circ}\text{F}$
<b>Accuracy</b>	2%
<b>Dimensions</b>	154 x 30 x 14 mm
<b>Battery</b>	1 x CR2032 3.0v Lithium Coin Cell

