



Intelligent Sensor LED Batten Lighting

LEDBTS Series: 18W and 36W sensor battens in standard 600mm & 1200mm models

The ENSA™ LED batten light series comprises truly customisable energy efficient lighting solutions that deliver unparalleled control over your lighting, without the need for a complex management system.

Each LED batten uses a fully-configurable ambient light sensor, 5.8GHz microwave motion sensor and light on-timer in tandem, achieving impressively low total energy consumption when compared to traditional twin-batten fluorescent tubes. They are perfect for areas with intermittent people traffic such as in stairwells, corridors, underpasses, car parks and more.

- Tailor your light use to further compound energy savings
- Adjustable light & motion sensing with on-time control
- Sensor can detect motion through glass and thin walls
- Built tough housing: IP65 dust and weather resistant
- · Control standby mode: completely off or half brightness
- Long lifespan LED lighting: rated for up to 50,000 hours

Series Specifications

Model	LEDBT18WS	LEDBT36WS
Product Image		
Series Name	LEDBTS Series: Standard LED Smart Batten	
Optical		
Light Output	1350lm	3240lm
Luminous Efficacy	75lm/W	90lm/W
Colour Temperature	6000K	
Colour Rendering Index	>70	
Beam Angle	140°	
Light Decay	< 15% at 20,000 hours	
Rated Lifespan	> 50,000 hours	
Electrical		
Power Consumption	18W	36W
Input Voltage	220 ~ 240VAC (50Hz)	
Power Factor	>0.9	
Dimmable	N/A	
Detection		
Ambient Light Sensor	3 ~ 2000lx (adjustable)	
Motion Detection	360° Microwave (5.8GHz) / 8m radius (adjustable)	
On-Time Delay	10s ~ 12min (adjustable)	
Standby Light Modes	Off (0% brightness)	
General		
Ingress Protection	IP65	
Plug / Socket / Base	Internal terminal block	
Reflector / Diffuser	Clear polycarbonate diffuser / Metal clips	
Operating Environment	-20°	°~50°C
Dimensions	600 x 86 x 65mm	1200 x 95 x 80mm
Photometry		
Illuminance at a Distance	Centre Beam Avg (lx) 1m 183 3.05 2m 46 6.10 3m 20 9.15 4m 11 12.20 5m 7	Centre Beam Avg (k) 1m 408 2.89 2m 102 5.79 3m 45 8.68 4m 26 11.58 5m 16
Luminous Light Distribution	90° 75° 60° 45° 15° 0° 15° 30°	90° 75° 60° 45° 15° 0° 15° 30°

Your local $\mathsf{ENSA}^{\scriptscriptstyle\mathsf{TM}}$ lighting solutions professional: