

## **Remote Control for Edison v2 Robot *RO-ED-REMOTE***

- **Can be used with two Edison robots from one remote**
- **Supplied with CR2025 battery**



### **Using the Remote Control with the Edison Robot v2**

Edison can respond to commands from the RO-ED-REMOTE control. See the attached barcode page to program your Edison Robot to respond to your remote control.

#### **How to program your Edison using the bar codes and the RO-ED-REMOTE**

- Place Edison facing the barcode on the arrow on the right
- Press the RECORD button (●) once
- Wait for the LED lights to come on,
- Then press the RECORD button (●) 2 more times
- Edison will drive over the bar code and stop
- While the red LED's on the Edison are still on,
- Point the remote at the Edison Robot
- Press the button on the remote control that you wish to use to program the barcode function



#### **Suggested remote control buttons to use with your Edison Robot**

- ▲ Drive Forward
- ▼ Drive Backward
- ▶ Turn Right
- ◀ Turn Left
- ③ Spin Right
- ① Spin Left
- ⑦ IR Learn Play Beep
- ⑨ Play a Tune



#### **You can also control a second Edison Robot with the same remote control, this is the suggested button configuration for your second robot**

- ② Drive Forward
- ⑧ Drive Backward
- ⑥ Turn Right
- ④ Turn Left
- # Spin Right
- \* Spin Left
- ⑤ IR Learn Play Beep
- ⑩ Play a Tune

